

PHOTO COUPLER

15229712 PC-900

RESISTOR

CRB25FX (1%)

13769162DO	3.6K
13769263DO	4.99K
13769173DO	10K
13769177DO	15K
13769178DO	16K
13769180DO	20K
13769181DO	22K
13769185DO	33K
13769188DO	43K
13769191DO	56K
13769197DO	100K
13769200DO	130K
13769264DO	140K
13769201DO	150K
13769203DO	180K
13769205DO	220K
13769213DO	470K
13769221DO	1M

KNY2W

13859106	(0.47Ω)
13859107	(0.82Ω)

POSISTOR

15229910	ERS-B33G122
----------	-------------

ARRAY

13919304	RM4-105J	1M	x 4
13910106	RM6-103K	10K	x 6
13919302	RM8-102J	1K	x 8
13919301	RM8-472J	4R7K	x 8
13829821	RM8-103K	10K	x 8
13919303	RM8-333J	33K	x 8
13919122	EXQ-D08E270J	27	x 8
13919317	EXQ-D08E680J	68	x 8
13919318	EXQ-D08E682J	6.8K	x 8
13919131	RM0889		
13919128	RM0688		
13919132	RM0891		
13919129	RM0689		
13919130	RM0690		

BENDER UNIT


2327571300 PB-6

OTHERS

068H049	LED guide H49
073H027	LED spacer H27
048H033A	Heat sink H33A
125569111	CR 1/3N (Lithium battery)
12199519	TF-758 (Fuse holder)

KEYBOARD

004H008 SK-361C (61 keys)



KEYBOARD PARTS
SK-361C (004H008)

NO	PART NO	DESCRIPTION
1	106H026	Natural key C F
1	106H027	Natural key D
1	106H028	Natural key E B
1	106H029	Natural key G
1	106H030	Natural key A
1	106H031	Natural key C' F'
2	106H032	Sharp key black
3	070H029	Key spring H29
4	061H086A	Chassis H86A
5	068H004	Guide bushing H4
6	101H141	Level felt H141
7	071H044	Contact leaf H44
8	071H051	Busbar 8P H51
	071H054	Busbar 5P H54
9	043H007	Switch unit 12P H7
	043H008	Switch unit 13P H8
10	104H029	Busbar holder H29
11	062H024	Chassis bracket H24
12	098H006	Key stopper H6
13	052H283-5	Matrix board H283-5
14	107H059	Cushion H59